


Model 757 Spray Gun



Ref. No.	Part No.	Description	Qty.
1 *	1234923	Grip and seat assy.	1
2	1234552	Gun grip	1
3 ***	1234876	Valve seat	1
4	1285565	Insert	1
5 **	1234922	Trigger and latch assy.	1
6	1234553	Trigger	1
7	1234554	Latch trigger	1
8	1234881	Latch spring	1
9	1177217	Roll pin, 3/32 x 5/8	1
10 ***	1278390	Wearclip	1
11 ***	1187961	Roll pin, 5/32 x 1	1
12	1234874	Adjusting sleeve	1
13	1112962	Set screw, hex head socket #8-36 x 3/16	1
14 ***	1185360	O-ring	1
15	1234875	Whirl	1
16 ***	15528	Gasket	1

Ref. No.	Part No.	Description	Qty.
17	14691	Disc, #3	1
***	28755	Disc, #4	1
***	14191	Disc, #5	1
***	15066	Disc, #6	1
	14192	Disc, #7	1
18	1234994	Nozzle cap	1
19	320107	Capscrew, socket head #8-32 x 3/4	1
20 ***	1177386	O-ring	1
21	1234877	Valve stem	1
22	1234992	Valve cap	1
23	1234880	Valve spring	1
24 ***	5269041	Valve Disc	1
25 ***	17236	Gasket	1
26	1236337	Adapter, 3/4" hose thread to 1/4" pipe thread	1

- * Complete assembly includes items 2-4.
- ** Complete assembly includes items 6-10.
- *** Items available in repair kit 5251845.