

**Model 1162 Automatic Air Grease Gun**




FIG. 6

NOTE: Illustration shows follower seal lip positioned for cartridge use.

**Model 1162 Automatic Air Grease Gun****Service Parts List**

1	1230	Hose 30"	Hose 30" Gasket Label Warning	1 1 1
2	5852	Coupler hydraulic	Coupler, midget	1
3	274985	Kit Outlet Check	Spring Housing Ball Check Spring Gasket	1 1 1 1
4	272065	Grease Tube	Container Assy. Label Warning	1 1
5	274984	Head	Head Machined Screw 10-32 x 1/4 Packing (head-tube) Gasket (handle-head) Wiper Rod Valve Vent/Loader	1 4 1 1 1 1
6	274983	Handle	Handle Machined Screw 10-32 x 1/4 Gasket (Handle-Head) Bumper Logo Left Logo Right Name plate Handle Grip	1 4 1 1 1 1 1 1
7	272068	Piston	Piston Assy. Screw 10-32 x 1/4 Gasket (Handle-Head)	1 4 1
8	274982	Trigger	Trigger Roll Pin	1 1
9	274981	Trigger Valve	Trigger Valve Roll Pin	1 1
10	271880	Packing	Packing	1
11	272072	Follower	Follower Assy.	1
12	272073	Spring, Piston	Return Spring	1
13	274980	Plunger	Plunger Assy.	1
14	272075	Crown Seal	Crown Seal	2
15	272076	Gasket	Gasket	1
16	272077	Wiper	Wiper Rod	1
17	272078	Handle	Handle	1
18	286134	Vent/Bulk Valve Kit	Vent/Bulk Valve Kit	1
19	286092	Hose Clip	Hose Clip	1
20	286093	Coupler Cap	Coupler Cap	1
21	11659	Air Nipple	Air Nipple	1